

User Manual

WISE-4471 Series

ADVANTECH

Enabling an Intelligent Planet

Advantech

IoT Wireless Sensor Node 資料收集模組

Model name 型號: WISE-4471

安全指示

1. 使用環境溫度：作業時：+60° C（最高環境溫度）
2. 請嚴格按照說明書操作並仔細閱讀安全指示。只有經過訓練的維修人員才能對設備進行維修。研華建議客戶在維修時向維修人員索取維修合同，並要求維修人員進行全部維修；否則設備的正常功能將可能受到影響。
3. 警告！請勿在設備工作或電源接通時移除設備蓋，以防觸電。
如遇下列情況，請由專業人員來維修：
 - 電源線或者插頭損壞；
 - 設備內部有液體流入；
 - 設備曾暴露在過於潮濕的環境中使用；
 - 設備無法正常工作，或您無法通過用戶手冊來使其正常工作；
 - 設備跌落或者損壞；
 - 設備有明顯的外觀破損。用濕抹布清洗設備前，請從插座拔下電源線。請使用濕布擦拭設備。請勿使用液體或去汙噴霧劑清潔設備。請勿在潮濕環境中使用設備。
4. 注意！為避免短路導致設備損壞，請勿讓液體流入設備。如有液體不慎濺入設備，請立刻移除受影響的部件並聯繫維修人員進行維修。
5. 電池注意事項：
未正確更換電池會有爆炸危險。更換電池時，僅可使用製造商建議的同類型電池，並請按照製造商的指示處理用過的電池。
本裝置使用過的電池若處理不當，可能會有起火或化學灼傷的風險。
請勿試圖拆解或其配件。
僅限由合格人員更換電池。
請勿將電池棄置火中，並請向當地機關確認廢棄處置方式。

如需瞭解有關本產品及研華其他產品的詳細資訊，請瀏覽我們的網站：

<http://www.advantech.com/>

如需技術服務與支援，請瀏覽我們的技術支援網站：

<http://support.advantech.com>

聯絡資訊：

研華股份有限公司

網站：www.advantech.com.tw

地址：台灣台北市內湖區瑞光路 26 巷 20 弄 1 號

電話：+886-2-27927818

NCC 警告聲明

第 12 條

針對經過認證的低功率頻率電氣機械，任何公司、商號或使用者未經許可均不得予以變更頻率、提高功率或變更原始設計的特性和功能。

第 14 條

低功率電氣機械的使用不可影響導航安全或干擾合法通訊，若發現干擾情事，將暫停服務至有所改善且干擾消失為止。

減少電磁波影響，請妥適使用

甲類警語：

警告使用者：這是甲類資訊產品，在居住的環境使用時，可能會造成輻射干擾，在這種情況下，使用者會被要求採取某些適當措施。

限用物質含有情況標示聲明書

Declaration of the **Present** Condition of the Restricted Substances Marking

PLM MDR NO: MDR-002889

設備名稱：資料收集模組 Equipment name: IoT Wireless Sensor Node		型號（型式）：WISE-4471 Type designation (Type)				
單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁺⁶)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
電路板	—	○	○	○	○	○
內外殼	○	○	○	○	○	○
線材	○	○	○	○	○	○
其它固定組件 (螺絲、螺柱)	—	○	○	○	○	○
網路卡	—	○	○	○	○	○

備考 1. “超出 0.1 wt %” 及 “超出 0.01 wt %” 係指限用物質之百分比含量超出百分比含量基準值。
Note 1: “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of **present** condition.

備考 2. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。
Note 2: “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

備考 3. “—” 係指該項限用物質為排除項目。
Note 3: The “—” indicates that the restricted substance corresponds to the exemption.

Copyright

The documentation and the software included with this product are copyrighted 2018 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free of defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Declaration of Conformity

CE Declaration of Conformity

This product passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

Federal Communications Commission

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance can void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Technical Support and Assistance

1. Visit the Advantech web site at www.advantech.com/support where you can find the latest information about the product.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
 - Product name and serial number.
 - Description of your peripheral attachments.
 - Description of your software (operating system, version, application software, etc.).
 - A complete description of the problem.
 - The exact wording of any error messages.

Warnings, Cautions and Notes

Warning! Warnings indicate conditions which, if not observed, can cause personal injury!



Caution! Cautions are included to help you avoid damaging hardware or losing data. e.g. There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or an equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



Note! Notes provide optional additional information.



Document Feedback

To assist us in making improvements to this manual, we welcome comments and constructive criticism. Please send all such comments, in writing, to: support@advantech.com

Package List

Before setting up the system, check that the items listed below are included and in good condition. If any item does not accord with the table, please contact your dealer immediately.

- WISE-4471-S250 module x 1
- Mounting bracket x 1
- Quick startup manual x 1
- China RoHS declaration x 1

Safety Instructions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 15. The power cord or plug is damaged.
 16. Liquid has penetrated into the equipment.
 17. The equipment has been exposed to moisture.
 18. The equipment does not work well, or you cannot get it to work according to the user's manual.
 19. The equipment has been dropped and damaged.
 20. The equipment has obvious signs of breakage.
21. **DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -40° C (-40° F) OR ABOVE 85° C (185° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.**
22. **CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER, DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.**
23. The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

DISCLAIMER: This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

Safety Precaution - Static Electricity

Follow these simple precautions to protect yourself from harm and the products from damage.

- Disconnect power before making any configuration changes. The sudden rush of power as you connect a jumper or install a card may damage sensitive electronic components.

Advantech

IoT Wireless Sensor Node 資料收集模組

Model name 型號: WISE-4471

Manufacture Info.

研華股份有限公司

網站: www.advantech.com.tw

地址: 台灣台北市內湖區瑞光路 26 巷 20 弄 1 號

電話: +886-2-27927818

Importer Info.

Company Name: Advantech Europe BV

Website: <http://www.advantech.eu>

Address: Science Park Eindhoven, Ekkersrijt 5708, 5692 ER Son, The Netherlands

Telephone No: 0031 40 267 70 27D

Contents

Chapter 1	Product Overview	1
1.1	Series Family and Specifications	2
1.2	Mechanical Design and Dimensions	2
1.3	LED Definition	2
1.4	Package Information	3
Chapter 2	Product Overview	5
2.1	General Specifications	6
2.1.1	Cellular Interface.....	6
2.1.2	Configuration Interface.....	6
2.1.3	General	6
2.1.4	Power.....	7
2.1.5	Software.....	7
2.2	I/O Specifications	7
2.2.1	Digital Inputs	7
2.2.2	Digital Outputs	7
2.2.3	RS-485 Port	7
2.3	Application Wiring	8
	Figure 2.1 WISE-4471-S250 Digital Output Wiring Diagram	8
	Figure 2.2 WISE-4471-S250 Digital Input Wiring Diagram.....	8
	Figure 2.3 WISE-4471-S250 RS-485 Wiring Diagram.....	9
2.4	Pin Assignment	9
	Figure 2.4 Pin Assignment.....	9
2.5	Block Diagram.....	10
	Figure 2.5 WISE-4471-S250 Block Diagram	10
Chapter 3	Hardware Installation	11
3.1	Interface Introduction	12
	Figure 3.1 WISE-4471 Interface Introduction	12
3.2	Mounting	12
	Figure 3.2 WISE-4471 Series Mounting Kit Dimensions	12
3.2.1	DIN-Rail Mounting.....	13
	Figure 3.3 WISE-4471 DIN Rail Mounting Installation	13
	Figure 3.4 WISE-4471 DIN Rail Mounting (front)	13
	Figure 3.5 WISE-4471 DIN Rail Mounting (back).....	14
3.2.2	Wall Mounting	14
	Figure 3.6 WISE-4471 Wall Mounting Installation	14
	Figure 3.7 WISE-4471 Wall Mounting	15
3.2.3	Pole Mounting	15
	Figure 3.8 WISE-4471 Pole Mounting Installation	15
	Figure 3.9 WISE-4471 Pole Mounting	16
3.3	Wiring & Connections.....	16
3.3.1	Power Supply Wiring.....	16
	Figure 3.10 WISE-4471-S250 Power Wiring	16
3.3.2	I/O Units	17
Chapter 4	System Configuration	19
4.1	Connection	20
4.2	Configuring WISE-4471 Using WISE Studio	20

4.2.1	Minimum System Requirements	20
4.2.2	Installing WISE Studio	20
4.2.3	A Brief Introduction to WISE Studio.....	21
4.2.4	Information Page	22
4.2.5	Connecting to a Cellular Network	23
4.2.6	I/O Status Configuration	25
4.2.7	System Configuration	34
4.2.8	Data Logger	37
4.2.9	Diagnostician	40
4.2.10	Push Notification.....	40
4.2.11	iSensing MQTT.....	41

Appendix A **iSensing MQTT..... 45**

A.1	iSensing MQTT Format for Publishing	47
A.1.1	Topic Format: Advantech/IMEI/data	47
A.1.2	Payload Format	47
A.1.3	Example.....	48
A.2	iSensing MQTT Format for Subscribing.....	50
A.2.1	Topic Format: Advantech/IMEI/ctl/doIndex.....	50
A.2.2	Payload Format	50
A.2.3	Example.....	51

Appendix B **EU Declaration of Conformity (DoC) 53**

B.1	EU Declaration of Conformity (DoC).....	54
-----	---	----


Chapter 1

Product Overview

1.1 Series Family and Specifications

Function	Model	Description
Wireless Sensor Node	WISE-4471-S250	Cellular IoT WSN with 6 digital inputs, 2 digital outputs, and 1-port RS-485

1.2 Mechanical Design and Dimensions



1.3 LED Definition

LED	Color	Indication	Behavior
Status	Green	Blink	2 Hz: No network connection. 0.5 Hz: Network connection is successfully initialized.
		Off	Idle
RF RX	Green	Blink	10 Hz, Receiving data via the network.
		Off	Idle
RF TX	Yellow	Blink	10 Hz, Sending data via the network.
		Off	Idle
Error	Red	Blink	2 Hz: RF related error with 4th (Full) signal strength LED blinking. 2 Hz: I/O related error with 3rd (Good) signal strength LED blinking.
		Off	No error
		On * 4	Full signal (RSSI Index ≥ 24) ($-117 \text{ dBm} \leq \text{RSSI}$)
Signal Strength	Yellow	On * 3	Good signal (RSSI Index ≥ 16) ($-125 \text{ dBm} \leq \text{RSSI} < -117 \text{ dBm}$)
		On * 2	Moderate signal (RSSI Index ≥ 8) ($-133 \text{ dBm} \leq \text{RSSI} < -125 \text{ dBm}$)
		On * 1	Poor signal (RSSI Index ≥ 0) ($\text{RSSI} < -133 \text{ dBm}$)
		All Off	No signal (Not registered to network, or registration denied)

COM RX	Green	On	Received response from slave device
		Off	Idle
COM TX	Yellow	On	Send request to slave device
		Off	Idle

1.4 Package Information

WISE-4471-S250

- 1 x WISE-4471-S250 module with internal antenna and terminal connector
- 1 x plastic wall-mounting bracket
- 1 x quick startup manual
- 1 x China RoHS declaration

Chapter 2

Product Overview

2.1 General Specifications

2.1.1 Cellular Interface


- Standards: 3GPP R.13 LTE Cat. M1/NB1
- Frequency Band: 2,3,4,5,8,12,13,20,28


2.1.2 Configuration Interface


- Interface: USB virtual COM port
- Connector: Micro-B USB
- USB Chipset: Silicon Labs CP210x
- Driver: CP210x USB to UART Bridge VCP Drivers

2.1.3 General

- Configuration Interface: Micro-B USB
- SIM: 3FF/Micro SIM
- Connector:
 - WISE-4471-S2xx: Plug-in screw terminal block (I/O and power)
 - WISE-4471-S4xx: M12 4-pin code-A male x 1 (power)
- M12: 8-pin code-D female x 1 (I/O)
- LED Indicator: Status, Error, Tx, Rx, Signal Level
- Mounting DIN: 35 rail, wall, pole and stack
- Dimension (W x H x D): 70 x 112 x 38 mm
- Certification: CE(RED), NCC, FCC, IC
- I/O connector: 3.5-mm spacing plug-in screw terminal block
- Power Connector: 3.5-mm spacing plug-in screw terminal block
- Real-time Clock (RTC) accuracy: ± 2 s/day
- Enclosure: PC+PBT
- Operation Temperature: $-20\sim 60^{\circ}\text{C}$ ($-4\sim 140^{\circ}\text{F}$)
- Storage Temperature: $-40\sim 85^{\circ}\text{C}$ ($-40\sim 185^{\circ}\text{F}$)
- Operating Humidity: 20~95% RH (non-condensing)
- Storage Humidity: 0~95% RH (non-condensing)

Note!  WISE-4471 modules can operate below 30% humidity. However, environments with low relative humidity are prone to problems with electrostatic discharge. Therefore, you should ensure that you take adequate precautions by using ground straps, anti-static floor coverings, or similar equipment whenever handling, especially in low-humidity environments.

Note!  Whether temperature and humidity can be measured depends on the type of sensor being used.

Note!  The SIM is not hot swappable, please restart the device after SIM card is removed or inserted.

2.1.4 Power

- Power Input Voltage: DC 10-50V
- Power Consumption: 1.7 W @ 24 V_{DC}

2.1.5 Software

- Utility: WISE Studio
- Driver: USB to UART Bridge (<https://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers>)
- Supported protocols: TCP/IP, UDP/IP, HTTP, HTTPS, TLS, DTLS, MQTT, CoAP, MQTT-SN, LWM2M
- Supports RESTful Web API.JSON format

2.2 I/O Specifications

2.2.1 Digital Inputs

- Channels: 6
- Logic level (dry contact)
 - 0: Open
 - 1: Close DI COM
- Supports 32-bit counter input function (maximum signal frequency, 3 kHz)
- Supports keep/discard counter value on power-off
- Supports frequency input function (maximum signal frequency, 3 kHz)
- Supports inverted digital input status

2.2.2 Digital Outputs

- Channels: 2
- Open collector to 30 V, 100 mA maximum for resistance load
- Inductive loads require an external diode to eliminate back-EMF when the digital output is OFF
- Supports 5-kHz pulse output
- Supports high-to-low and low-to-high delay output

2.2.3 RS-485 Port

- Number of Ports: 1
- Port Connector: 3.5mm spacing plug-in screw terminal block (shared with I/O and power)
- Baud Rate (bps): 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200
- Data Bits: 7, 8
- Stop Bits: 1, 2
- Parity: None, Odd, Even
- Signals: DATA+ and DATA-
- Protection: 15 kV ESD
- Supported Protocol: Modbus/RTU (Total 64 address by max. 30 instructions)

2.3 Application Wiring




Figure 2.1 WISE-4471-S250 Digital Output Wiring Diagram




Figure 2.2 WISE-4471-S250 Digital Input Wiring Diagram




Figure 2.3 WISE-4471-S250 RS-485 Wiring Diagram

2.4 Pin Assignment




Figure 2.4 Pin Assignment

2.5 Block Diagram




Figure 2.5 WISE-4471-S250 Block Diagram

Chapter 3

Hardware Installation

3.1 Interface Introduction




Figure 3.1 WISE-4471 Interface Introduction

3.2 Mounting

Applicable installation methods are briefly described in the following sections.




Figure 3.2 WISE-4471 Series Mounting Kit Dimensions

3.2.1 DIN-Rail Mounting

WISE-4471 modules can be fixed to a cabinet with mounting rails. Use a flathead screwdriver to fasten the DIN rail adapter to your module. You can then use the end brackets included in the package in order to keep it from sliding.




Figure 3.3 WISE-4471 DIN Rail Mounting Installation




Figure 3.4 WISE-4471 DIN Rail Mounting (front)




Figure 3.5 WISE-4471 DIN Rail Mounting (back)

3.2.2 Wall Mounting

The plastic wall mounting bracket that comes with the module can be used to mount it on a wall, panel, or cabinet.




Figure 3.6 WISE-4471 Wall Mounting Installation




Figure 3.7 WISE-4471 Wall Mounting

3.2.3 Pole Mounting

For pole mounting, feed the pole mounting ring through the hole in the middle of the module. The pole mounting ring needs to be unlocked with a screw driver before it can be inserted through the module. To mount the module on the pole, tightly lock the pole-mounting ring.




Figure 3.8 WISE-4471 Pole Mounting Installation




Figure 3.9 WISE-4471 Pole Mounting

3.3 Wiring & Connections

This section provides basic information on wiring the power supply and I/O units.

3.3.1 Power Supply Wiring

WISE-4471 modules are designed to support a standard industrial unregulated 24-VDC power supply. For other applications, they can also accept +10 to +50 VDC input with 200 mV of peak-to-peak power ripple. The immediate ripple voltage should be maintained between +10 and +50 VDC. The screw terminals labeled "+Vs" and "-Vs" are for the power supply wiring.




Figure 3.10 WISE-4471-S250 Power Wiring

3.3.2 I/O Units

WISE-4471 uses a plug-in screw terminal block for the interface between WISE-4471 and field devices. The following information is critical when connecting electrical devices to I/O modules. The terminal block accepts wires from 0.5 mm to 2.5 mm.


- Use the correct wire gauge (note that the terminal block accepts wires from 0.5 to 2.5 mm).
- Use a continuous length of wire (do not join separate wires to form a continuous length).
- Use the shortest wire length possible.
- Use wire trays for routing wherever possible.
- Avoid running wires close to high-energy wiring.
- Avoid running input wiring near output wiring.
- Avoid creating sharp bends or kinks in the wires.

Chapter 4

System Configuration

4.1 Connection

1. Open the rubber cover on the side of the module, you will see the micro SIM card socket. Please insert your SIM card here and note that only the micro SIM can be used.
2. Download and install USB driver from: <https://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers>
3. Configure the USB port through the following steps. Please insert micro-B USB cable here and note that it doesn't provide power for the WISE module.
4. Plug a DC power source into the +Vs, -Vs pin of your module to turn on the power.



4.2 Configuring WISE-4471 Using WISE Studio

4.2.1 Minimum System Requirements

The minimum system requirements for WISE Studio are as follows:


- Microsoft Windows 7 or above
- Microsoft NET framework 3.5 or above
- Internet Explorer 10 or above

4.2.2 Installing WISE Studio

The latest version of WISE Studio is available on the Advantech support site: <http://support.advantech.com/>. To install the program, download the installation file and execute it locally.

4.2.3 A Brief Introduction to WISE Studio

WISE Studio is a new configuration tool for WISE modules. All configurations are based on a web interface, so you will notice that different models have similar configuration pages. For WISE modules configured by Ethernet, LAN, or WLAN, WISE Studio enables communication with the internal web server inside the WISE module. For those configured by USB, WISE Studio will execute a web server on the computer that the software is installed on. The web server will use the USB interface to communicate with the WISE module. Information will be viewable via the embedded web page or you can open the web page via browsers.



Communication Box

In this box, there are several communication interfaces for configuring different WISE modules. The WISE-4471 series uses the USB-serial interface for configuration.

- **Refresh:** Pressing this button refreshes the USB-serial interface.
- **USB-Serial:** This block is for connecting to a WISE module via USB. The available USB-serial port number will be shown here. Click **Go to Configuration** to connect the USB COM port.

USB-Serial Configuration Page

After **Go to Configuration** is clicked, all available USB COM ports will be displayed. Choose the COM port that you are going to configure and click **Connect** to open the **Configuration** page. You can further click **Open in Browser** to use your default browser to configure the WISE module (IE is the default browser embedded in WISE Studio).

4.2.4 Information Page

Module Information

This page displays the name of the module and related information. Click Go to Configuration to view or change the settings:

- **Model Name:** Model of the WISE module.
- **Customized Name/UUID:** Refers to the model name and UUID of the module. The default UUID is a combination of the model name and IMEI. You can modify this value.
- **Location Information:** Information on the location of the module is given here.
- **Description:** Any comments describing this module can be given here.

Information

Module Information

Model Name	WISE-4471-S250UA
Customized Name	WISE-4471-S250UA
UUID	WISE-4471-S250UA_0047604
Location	
Description	
Working Mode	Normal Mode

[Go to Configuration](#)

Cellular Information

This block shows information on the cellular RF module and cellular network status.

- **PIN Status:** The PIN code status of the SIM card.
- **Register Status:** Registration status with the cellular network operator.
- **Current Service Mode:** Network service mode (e.g., LTE CAT-NB1)
- **Signal Strength:** Indicates reference signal receiving power (RSRP) of the cellular network.
- **IP Address:** IP address assigned by the cellular network.
- **Operator Name:** Name of the cellular network operator.
- **Modem Manufacturer:** Manufacturer of the RF module.
- **IMEI Code:** International Mobile Equipment Identity of the current modem.
- **IMSI Code:** International Mobile Subscriber Identity of the current SIM card.
- **ICCID Code:** Integrate Circuit Card Identity.

Cellular Information			
PIN Status	READY	Register Status	Registered
Current Service Mode	LTE CAT-NB1	Signal Strength	-115dBm
IP Address	10.99.255.55	Operator Name	466 97
Modem Manufacturer	u-blox	Modem Firmware	L0.0.00.00.05.06 [Feb 03 2018 13:00:41
IMEI Code	352753090047380	IMSI Code	466978000200249
ICCID Code	89886971708800001991		

[Refresh](#)

Firmware Information

In this page, you can check the model name and module description. The firmware version is also shown at the end of the configuration web page. To update the firmware, go the **Firmware Version** section.

- **Module Name:** Name of the WISE module.
- **Module Description:** Description of the WISE module.
- **Firmware Description:** Firmware and bootloader version of the WISE module.
- **Web Page Version:** The web page version is given at the bottom of the Configuration page before the copyright information.

Module Information		
Module Name	Module Description	Firmware Description
WISE-4471-S250UA	NB-IoT WSN with 1-port RS-485 and DIO	Fw:A9.99 B99, Bootloader:A1.00 B00, A/D Fw:A1.01 B00, A/D Bootloader:A1.01 B00

Version : A0.00B04, Copyright © 2018 By Advantech

4.2.5 Connecting to a Cellular Network

Enter the PIN Code

First, insert a SIM card into the WISE module, and then go to the **Configuration** page and click the **Cellular** tab. Enter the PIN of the SIM card in the **PIN Authentication** dialog box. Selecting the **Auto Write PIN Code** check box will save the PIN code to the WISE module.

Cellular Information

After the PIN code has been entered, information on the cellular network will be available in the **Cellular** tab:

- **PIN Status:** The PIN code status of the SIM card.
- **Register Status:** Registration status with the cellular network operator.
- **Current Service Mode:** Network device mode (e.g., LTE CAT-NB1).
- **Signal Strength:** Indicates reference signal receiving power (RSRP) of the cellular network.
- **IP Address:** IP address assigned by the cellular network.

- **Operator Name:** Name of the cellular network operator.
- **Modem Manufacturer:** Manufacturer of the RF module.
- **IMEI Code:** International Mobile Equipment Identity of the modem.
- **IMSI Code:** International Mobile Subscriber Identity of the SIM card.

Configuration

Information **Cellular** Network App Time & Date Control Cloud Firmware

Cellular Information Cellular Config

Cellular Information

PIN Status	READY	Register Status	Registered
Current Service Mode	LTE CAT-NB1	Signal Strength	-114dBm
Operator Name	466 97	IP Address	10.99.255.55
IMEI Code	352753090047380	IMSI Code	466978000200249
Modem Manufacturer	u-blox		

Cellular Configuration

Basic setting

After the SIM card has been inserted into the WISE module, it can be configured in this page:

- **Auto Write PIN Code:** Enables the PIN code to be saved to the WISE module.
- **PIN Code:** Configure or modify the PIN code here.
- **Access Point Name (APN):** Configure the APN of the cellular network provider.

Configuration

Information **Cellular** Network App Time & Date Control Cloud Firmware

Cellular Information Cellular Config

Basic Setting Advanced Setting

Basic Setting

Auto Write PIN Code

PIN Code

Access Point Name

Advanced Setting

RAT Type: Select the operating mode category.

Band Mask: Select the specific band by shortening the connection time.

The screenshot shows the 'Configuration' page with a navigation bar containing 'Information', 'Cellular', 'Network App', 'Time & Date', 'Control', 'Cloud', and 'Firmware'. The 'Cellular' tab is active, showing 'Cellular Information' and 'Cellular Config' sub-sections. The 'Advanced Setting' sub-section is highlighted, containing a 'RAT Type' dropdown menu set to 'LTE CAT-NB1' and a 'Band Mask' row with checkboxes for bands 2, 3, 4, 5, 8, 12, 13, 20, and 28. The '28' checkbox is checked. A green 'Submit' button is located at the bottom right of the form.

4.2.6 I/O Status Configuration

4.2.6.1 Digital Input Status

The value of all digital input channels can be determined from the related LED display in the DI tab (green LED = "logic high"; grey LED = "logic low").

IO Status

The screenshot shows the 'IO Status' page with tabs for 'DI', 'DO', and 'COM1'. The 'DI' tab is active, showing 'Status' and 'Configuration' sub-sections. The 'Status' sub-section contains a table with two rows of digital input channels.

Channel	Mode	Status
0	DI	
1	DI	

Configuration

The digital input channels support several operation modes and can be configured from this page.

- **Channel:** Select the channel to be configured.
- **Tag Name:** Each channel can be given a tag name for identification.

- **Mode:** The operation mode of each channel can be configured here, or channels can be disabled to improve the performance of enabled channels. After a channel has been configured, pressing **Submit** at the end of this page will apply the changes.
- **Channel Mask:** Each channel can be disabled individually for reducing data traffic during communication.
- **Refresh:** Refresh the configuration.

DI DO COM1

Status Configuration

Configuration

Channel
0

Tag Name
W4471_047604-DI0

Mode
DI

Channel Mode is used for Channel Status Display only.

Channel Mask
 Enabled/Disabled

Refresh
Refresh

- **Invert Signal:** WISE digital input channels support the invert digital input status function. To enable/disable this, select the **Invert Signal** check box on the Configuration page.
- **Digital Filter:** Digital input channels have a digital filter that can remove high-frequency noise. The filter can be enabled/disabled by clicking the Digital Filter check box. When the filter is enabled, the minimum acceptable signal width can be defined in the **Min. Low Signal Width** and **Min. High Signal Width** boxes (increment: 0.1 ms).

Invert Signal
 Enabled/Disabled

Digital Filter
 Enabled/Disabled

Min. Low Signal Width
1 0.1ms

Min. High Signal Width
1 0.1ms

- Counter:** When counter mode is selected for a given channel, a counter will count the number of pulses in the digital signal from that channel and then record the value to the register. In the **Status** page, the current count value of the selected channel is displayed in the **Counter value** box. The counter can be started/stopped by pressing **Start/Stop**, which is located beside the counter value. The counter can be reset (the value in the register will be initialized to the startup value, which is zero by default) by clicking Reset. The predefined startup value will be the value shown in the **Counter value** box. When this value is reset, either by pressing **Reset** on the **Status** page or by issuing a command, it will return to the startup value, which is zero by default.

If **Keep Last Value** is enabled, the last counter value will be kept in the register when the module is powered off. When the module is powered on, the counter will continue to count from that value. When this function is disabled, powering off the module will cause the counter to be reset and the count value in the register to be reset to zero.
- Frequency:** For pure digital input channels, WISE modules support frequency mode, which calculates the frequency of the digital input signal of the selected channel. The frequency value will be displayed in the **Frequency value** box on the DI Status page. **Precision** can be configured here to decide the unit of frequency for different kind of input range. **Value Reset Time** function is design for deciding when will the frequency value been reset to zero if pulse bandwidth longer than expect.

The screenshot shows a configuration interface with the following elements:

- Counter: Startup Value:** A text input field containing the number "0" and a "times" unit button to its right.
- Counter: Keep Last Value:** A checkbox that is currently unchecked, with the text "Enabled/Disabled" to its right.
- Frequency: Precision:** A dropdown menu currently set to "0.1 Hz".
- Frequency: Value Reset Time:** A text input field containing the number "100" and a "0.1 sec" unit button to its right.
- Submit:** A green button with a checkmark icon and the text "Submit" located at the bottom right of the form.

- Low-to-High Latch:** Under low-to-high latch mode, once a digital input channel detects that the logic level has changed from low to high, the logic status will remain as "logic high" until the latch is cleared manually, which will return the logic status to "logic low." The logic status is viewable on the latch status LED display on the **DI Status** page. Clear the latch by clicking **Clear** on this page.
- High-to-Low Latch:** Under high-to-low latch mode, once a digital input channel detects that the logic level has changed from high to low, the logic status will remain as "logic low" the latch is cleared manually, which will return the logic status to "logic high." The logic status is viewable on the latch status LED display on the **DI Status** page. Clear the latch by clicking **Clear** on this page.

IO Status

DI DO COM1

Status Configuration

Status

Channel	Mode	Status
0	Low to High Latch	<input checked="" type="checkbox"/> Clear
1	High to Low Latch	<input checked="" type="checkbox"/> Clear

4.2.6.2 Digital Output Status

The values of all digital output channels can be controlled via the status switch, the color of which indicates the current value of the digital output channel.

IO Status

DI DO COM1

Status Configuration

Status

Channel	Mode	Status
0	DO	<input type="checkbox"/> OFF
1	DO	<input type="checkbox"/> OFF

Configuration

The digital output channels support several operation modes and can be configured from this page.

- **Channel:** Select the channel to be configured.
- **Tag Name:** Each channel can be given a tag name for identification.
- **Mode:** The operation mode of each channel can be configured here, or channels can be disabled to improve the performance of enabled channels. After a channel has been configured, pressing **Submit** at the end of this page will apply the changes.
- **Channel Mask:** Each channel can be disabled individually for reducing data traffic during communication.
- **Refresh:** Refresh the configuration.

The screenshot shows a web interface for configuring a digital output channel. At the top, there are navigation buttons for 'DI', 'DO', and 'COM1'. Below these are tabs for 'Status' and 'Configuration'. The 'Configuration' tab is selected, displaying a form with the following fields:

- Channel:** A dropdown menu showing '0'.
- Tag Name:** A text input field containing 'W4471_047604-DO0'.
- Mode:** A dropdown menu showing 'Pulse Output'.
- Channel Mask:** A checkbox labeled 'Enabled/Disabled'.
- Refresh:** A blue button with a circular arrow icon and the text 'Refresh'.

Below the Mode dropdown, there is a warning icon and the text: "All data will be cleared in the data logger if Channel Mode is changed."

- **FSV (Fail-Safe Value):** The digital output channels can be set to generate a predefined value when communication between a host controller and a WISE digital module is broken. To do this, select the FSV check box for the module to set the output channel to "logic high" when the WDT times out. If the FSV check box is clear, the module will set the output channel to "logic low" if the WDT times out. To set the module so that the **FSV** is triggered by the WDT, go to **Network App** on the **Configuration** page to enable **Communication WDT Trigger FSV** for all of the module's output channels, and then set the communication WDT mode to "Communication WDT." The default host idle time is 720 s, and this can be configured by entering a value in the **Host Idle (Timeout Sec)** box (unit: s) in this page.
- **Pulse Output:** In pulse output mode, the selected digital output channel can generate a continuous pulse train or finite pulses. The pulse width can be set by entering a value in the **Low Signal Width** and **High Signal Width** boxes on the **Configuration** page (increment: 0.1 ms). The frequency and duty cycle of the pulse output signal will be calculated automatically and displayed in the Output frequency and Duty cycle boxes, respectively. Whether a continuous pulse train or finite pulses will be generated is determined by clicking **Continuous** or **Fixed total**, respectively. The number of pulses to be generated can be set by entering

the value in the box to the right of **Fixed total**. After the pulse output mode has been selected, click **Start** or **Stop** to generate or stop the pulse output.

The screenshot shows a configuration interface with the following fields:

- FSV**: A checkbox labeled "True/False" which is currently unchecked.
- Low Signal Width**: A text input field containing "1" and a unit selector showing "0.1ms".
- High Signal Width**: A text input field containing "1" and a unit selector showing "0.1ms".
- Output frequency**: A text input field containing "5000" and a unit selector showing "HZ".
- Duty cycle**: A text input field containing "50" and a unit selector showing "%".

A green "Submit" button with a checkmark icon is located at the bottom right of the form.

- **Low-to-High Delay:** Low-to-high delay mode is similar to digital output mode; the only difference is that there will be a time delay when the output value changes from "logic low" to "logic high." The delay time can be defined by entering its value in the Delay Time box on the **Configuration** page. The digital output value can be controlled by clicking **DO**; the current value can be viewed from the digital out status LED display on the **DO Status** page.
- **High-to-Low Delay:** High-to-low delay mode is similar to digital output mode. The only difference is that there will be a certain time delay when the output value changes from "logic high" to "logic low." The delay time can be set by entering its value in the **Delay Time** box on the **Configuration** page. The digital output value can be controlled by clicking **DO**; its current value can be viewed through the digital output status LED display in the **DO Status** page.

The screenshot shows a configuration interface with the following field:

- Delay Time**: A text input field containing "1" and a unit selector showing "0.1ms".

A green "Submit" button with a checkmark icon is located at the bottom right of the form.

4.2.6.3 COM1 (RS-485 Port)

The WISE-4471-S250 has one RS-485 port for Modbus gateway functionality; thus, you can use this port to poll data from RS-485 Modbus/RTU slave devices such as the ADAM-4000 series or ADAM-5000/485 series.

Status

Go the **COM1** tab to check the status or to configure the RS-485 Modbus master function. A total of 64 addresses for all Modbus slaves can be mapped as the WISE module I/O. These 64 addresses can be coils or registers; coils will be mapped as extension bits of the WISE module, and registers will be mapped as extension words of the WISE module. In the **COM1** status tab, the bits and words are shown on individual pages.

- **Channel:** Indicates the number of bits. A maximum 64 bits can be shown here but users may map fewer than 64 coils as bits. Doing so makes the empty bits invalid. The same applies to words, which may also have empty channels.
- **Value:** Indicates the value polling from mapped address.
- **Status:** Indicates the status of each bit or word. If a channel is empty and has not been mapped to a Modbus slave address, its status will be "Unavailable."
- **Slave ID:** Indicates the Modbus slave ID of RS-485 Modbus slave devices.
- **Slave Address:** Indicates the address of a bit or word from an RS-485 Modbus slave device.

For a writable bit or word, you can click **Edit** to switch to edit mode. Here, you can change the values and then click **Apply** to write the Modbus addresses individually.

The screenshot shows the 'IO Status' interface with the 'COM1' tab selected. Below the tab are three sub-tabs: 'Status', 'Modbus/RTU Configuration', and 'Diagnostician'. The 'Status' sub-tab is active, showing a 'Bit Status' section with a 'Show 16 entries' dropdown and an 'Edit' button. Below this is a table with the following data:

Channel	Value	Status	Slave ID	Slave Address
0		Unavailable	0	0

Modbus Configuration - Common Settings Tab

In this tab, you can configure the parameters of the RS-485 port.

- **Baud Rate:** 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 bps
- **Data Bit:** 7, 8
- **Stop Bit:** 1, 2
- **Parity:** None, Odd, Even
- **Slave Response Timeout:** For setting the reply time for Modbus slaves.
- **Delay between Polls:** For setting the delay time between each Modbus instruction.
- **CRC Check:** For disabling the CRC check to ignore Modbus CRC errors.

Modbus/RTU Configuration

Common Setting
Rule Setting

Baud rate

Data Bit

Parity

Stop Bit

Slave response timeout ms

Delay between Polls ms

CRC Check Disable Enable

✔ Submit

Modbus Configuration - Rule Setting Tab

In this tab, you can configure the Modbus address of end devices you would like to poll.

- **Rule:** There is a maximum of 30 rules that each COM port can support. Each rule can be for a different slave device, meaning that there can be a maximum 30 of devices connected to the COM port. Alternatively, you can use all of the rules for polling different addresses on the same slave device.
- **Slave ID:** Different slave devices in the same RS-485 port have different slave IDs; enter the slave address of the Modbus devices that are connected to the WISE module here.
- **Type:** This device supports Modbus data types: 01 Coil Status (0x), 02 Input Status (1x), 03 Holding Registers (4x), and 04 Input Registers (3x). After one of the types has been configured in the rule, the rule will be enabled and the COM port will start polling after the configuration has been submitted successfully.
- **Start Address:** Enter the first address number that you are going to poll. The address base is 1; if you are going to polling the first address of a holding register (i.e., 40001), then simply enter the number "1" here (you do not need to enter the entire address "40001").
- **Length:** Enter the length of the address that you are going to poll in this rule. For example, if you are going to poll 40001~40008, set the length to "8." Note that since each COM port can poll a maximum of 64 addresses, the maximum length is 64 and the total number of all rules should not exceed 64.
- **R/W:** Here, you can set whether the address in this rule will be read or written. For coil statuses and holding registers, you can make these addresses read-only or write-only to reduce the polling effort.
- **Scan Interval (unit: s):** Here, you can set the scan interval for the COM port to poll Modbus slave devices. The COM port will optimize the scan interval according your setting. However, the read scan interval may also depend on factors such as the Baud rate, slave device response time, delay between polls, and so

on. See the **Diagnostician** page to check the real response time as a reference for the scan interval value.

- **Mapping Channel:** When the Modbus address of slave devices has been configured in each rule, these addresses will also be mapped to the WISE module. Coils and registers of Modbus slave devices will be mapped as bits for RESTful web service. There are 64 continuous channels of bits and another 64 continuous channels of words that can be mapped. Please ensure that the channels for each rule do not overlap.
- **Log:** Here, you can set whether the data that have been polled from this rule will be logged in the data logger.
- **Deviation/Change of Status (COS):** When this check box has been set, the difference of polling values between the current poll and the last poll can trigger the deviation/COS (change of state) for push data or log data.
- **Rule Status:** The web configuration interface will check whether the rule settings have any overlap or conflict. The enabled rules, which are enable the rule by setting the **Type** value, should have a green icon so that a "Submit" message will be shown for you to confirm submitting the rules.

Note! After you have configured the rules, click Submit to apply them.



Note! After you have changed the rule configurations, logged data in the data logger will be cleared to accommodate the new data structure of the data logger under the new configuration.



Note! You can hover your mouse over the table title rows to view tooltips.



IO Status

DI DO **COM1**

Status Modbus/RTU Configuration Diagnostician

Modbus/RTU Configuration

Common Setting Rule Setting

Rule	Slave ID	Type	Start Address	Length	R/W	Scan Interval	Mapping Channel	Log	Deviation/COS	Deviation Value	Rule Status
0	1	Disable ▾	1	1	R ▾	60	0	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3276	✘
1	1	Disable ▾	1	1	R ▾	60	0	<input checked="" type="checkbox"/>	<input type="checkbox"/>	3276	✘

Diagnostician

Since different devices will have different response times, the WISE-4471 provides a diagnostics function for testing the response time of each rule. This is intended to reduce the scan interval. You can refer to the response time on this page when configuring the **Scan Interval** in **Rule Setting** pages. You can reset the test result on this page by clicking **Reset Response Time**.

IO Status

Rule	Current Response Time(ms)	Max Response Time(ms)	Min Response Time(ms)	Status
0	0	0	65535	Unavailable
1	0	0	65535	Unavailable

4.2.7 System Configuration

Network Application

- **Host Idle (timeout sec):** Decides the availability of the TCP connection between the host controller and WISE. MCU-based WISE modules support four TCP connections at the same time for visiting users. It means WISE can be visited by four TCP hosts at the same time, and is not able to connect a fifth host. In this case, if one of the hosts stops communicating with the WISE module for longer than the configured host idle time, default 720 seconds, for example, the WISE module will close the TCP connection with the host.
- **Communication WDT:** After configuring Host Idle time, and will be triggered when all TCP connections are closed. This includes all hosts which visit WISE and also the communication between remote servers like private servers. Once the WDT is enabled, it will trigger systems events like FSV of output channel or system log.
- **Communication WDT trigger FSV:** Decide whether FSV of output channel will be triggered by communication WDT.
- **Reboot Interval:** Decide the time interval in minute to reboot WISE module when WISE module is not able to connect to cellular base station.
- **RF Reset Interval:** Decide the time interval in minute to reset the RF module in WISE module when WISE module is not able to connect to cellular base station.

Configuration

Information Cellular **Network App** Time & Date Control Cloud Firmware

Network Application

Communication WDT trigger FSV	Disabled
Hostile (Timeout Sec)	720
Communication WDT Mode	Disabled
Reboot Interval (Min)	10
RF Reset Interval (Min)	5




Time & Date

WISE modules have a built-in RTC that allows you to view the current time, set the time zone, and adjust the time by pressing **Click Me** to read the time from host devices.

Configuration


Information Cellular Network App **Time & Date** Control Cloud Firmware

Local Time

Current Time	2018-02-21T15:38:28+08:00	
Time Zone	(GMT+08:00) Taipei	
Time Calibration	 2018-02-21T15:38:28	


Control

- Restore to Default: The system configuration will be cleared and restored to factory default settings when clicking the icon.
- System Restart: This module's system will reboot when clicking the icon.




Firmware

To update the firmware, go to the **Firmware** page in **System Configuration** and click the icon of the file you wish to use in the update. You can find the latest official firmware releases on the Advantech support site (<http://support.advantech.com/>). You can also upload the configuration file or export the configuration file here.



4.2.8 Data Logger

The WISE-4471 series supports data logging. The I/O status can be logged in and queried from the module with up to 10,000 records. WISE-4471 also supports minimum 100,000 program-erase cycle per sector. Before you start the log function, please ensure that the RTC inside the WISE module has the correct time. A battery is used to store the time in the RTC but there may be some discrepancy due to the accuracy of the RTC.



Data Configuration

To choose the method that will be used to log data, go to the **Log Conditions** section in **Data Configuration**. Selecting the **By Period** check box enables periodic logging, and the log period can be set in the following field (increment: 0.1 s; a value of "600" here means that the I/O status will be logged every minute). If you select the **By Communication WDT** check box, the I/O status will be logged once the WDT condition has been met.

All data can be stored even when the module is powered off. You can clear all data in the logger when powering up the WISE module by selecting the **Clear Log when Power Up** check box. When the memory is full, the logger will stop logging unless you select the **Circular Log when Memory Full** check box, which will cause the module to overwrite the memory.

To set which I/O channel's status will be logged and whether a change of the status will also be logged, go to the **Channel Fields** tab. Note that the log memory will be cleared when any parameters are changed in the **Channel Fields** or in **IO Fields**.

For digital channels, select the **Log Enabled** check box to periodically log the status of the selected channel. Alternatively, select the **Change of State** check box to trigger data logging when a status change occurs.

Log Data

By Channel		
DI		DO/Relay
Channel	Log Enabled <input type="checkbox"/>	Change of State <input type="checkbox"/>
0	<input checked="" type="checkbox"/>	<input type="checkbox"/>
1	<input checked="" type="checkbox"/>	<input type="checkbox"/>

The WISE data logger function can log the I/O status as well as system events for module diagnostics and troubleshooting. You can decide type of system events you would like to log.

Data Logger

[Data Configuration](#) [Logger Configuration](#) [Local Data Query](#)

[I/O Configuration](#) [System Configuration](#)

Log System Events

- Cellular Info
- Cellular CME Error
- Communication WDT

Logger Configuration

On this page, you can enable the local memory storage function. There are separate switches for enabling the logging of I/O data or system data. Simply turn ON the switches to enable logging.

[Data Configuration](#) [Logger Configuration](#) [Local Data Query](#)

Memory Storage

I/O Log OFF

System Log ON

Local Data Query

You can query data that have been logged in the WISE module. Queries that are output to file will be saved in .Json format. You can visit <https://json-csv.com/> to convert the data from .Json to .Csv.

Before performing a query, you can first configure the format of the file. Here, you can choose whether the data will include a UUID or IMEI, and you can also choose the type of time stamp. WISE modules support Local Date and Time (GMT) format will have time stamps like "2015-08-27T15:20:29+08:00," and those that support Coordinated Universal Time (UTC) format will have time stamps like "1440660089."

After the data format has been selected, the data can be filtered by selecting **Amount of Latest Data** (to query a certain number of data entries) or **Time Filter** (to query data entries within a specific period of time). To query all data (assuming it is not too large), you can also select **No Filter Enabled**.

Now you can click **Query** to query the data from local memory. Then, the data will be shown in a chart and table. Click **Save** to save the data from the WISE module in .Json format, or click **Clear** to clear all data in local memory.

4.2.9 Diagnostician

The **Diagnostician** page indicates the operating status of the WISE module. The status of each function is shown on this page for easy troubleshooting.

WISE-4471-S250UA

Information
Configuration
I/O Status
Advanced
Access Control
Data Logger
Diagnostician

Diagnostician

Name	Description	Value
Data Logger	Event Status	Normal

Version : A0.00B02 20180511, Copyright © 2018 By Advantech

4.2.10 Push Notification

For cloud logger functions such as the **iSensing MQTT** function, data are extracted from the local memory of the WISE module. You can pack data from the WISE data logger into a file and then push the file to a web server whenever the log condition is triggered.

The WISE module will push a notification in .Json format to your MQTT broker. You can switch the **I/O Log** to **ON**, and the WISE module will then start pushing the latest logged data to the MQTT broker.

WISE-4471-S250UA

Information
Configuration
I/O Status
Advanced
Access Control
Data Logger
Diagnostician


Push Notification (JSON format)

I/O Log OFF

System Log OFF


4.2.11 iSensing MQTT

WISE-4471 support MQTT function, go to “Configuration \ Cloud” and select “iSensing MQTT”. Enter the Host Name of MQTT broker, here we use public broker provided by HiveMQ for demonstration.



The screenshot shows the 'Configuration' page with a 'Cloud' tab selected. Under 'Cloud Configuration', the 'Select Service' dropdown is set to 'iSensing MQTT'. In the 'Setting' section, the 'MQTT Host Name' is 'broker.hivemq.com' and the 'Port Number' is '8000'.

Then go to “Advanced \ Data Logger \ Data Configuration”, user can decide the update period in “Log Conditions”. The minimum update period is 10 second, so user can configure 100 (0.1 sec) as following figure.



The screenshot shows the 'Data Logger' configuration page for device WISE-4471-S250UA. The 'Data Configuration' tab is active. Under 'Log Conditions', the 'By Period' checkbox is checked with a value of '100' and a unit of '0.1 sec'. The 'By Communication WDT Log' checkbox is also checked.

User can decide which channel of data that would like to update periodically, or update by event (Change of State) can also been configured here.

Log Data

By Channel		
DI		DO/Relay
Channel	Log Enabled <input type="checkbox"/>	Change of State <input type="checkbox"/>
0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

After data update condition been decided by previous step, go to “Logger Configuration” and enable “I/O Log” in “Push Notification”, then WISE will star to update the data.

Data Logger

Data Configuration **Logger Configuration** Local Data Query

Push Notification (JSON format)

I/O Log

System Log

Please be noted that user need to unplug USB cable from the micro-USB configuration port on WISE before start updating data. If the USB port been connected, WISE will stop update data and waiting for configuration.

Go to HiveMQ web site <http://www.hivemq.com/demos/websocket-client/>, enter the Host and Port as following figure, then click “Connect”.


Connection

Host

Port

ClientID


Go to “Subscriptions” block, and click “Add New Topic Subscription”



Enter the topic “Advantech/IMEI_Code/data”, you can find the IMEI code by WISE-Studio, it’s in the page of “Configuraiton \ Cellular \ Cellular Information”

A screenshot of a subscription configuration form. It includes a "Color" field with a red square, a "QoS" dropdown menu set to "0", and a "Subscribe" button. Below these is a "Topic" input field containing the text "Advantech/IMEI_Code/data".


After subscribe the topic of WISE, you can see the data from WISE.



Appendix **A**


iSensing MQTT

MQTT (message queuing telemetry transport) is a publish/subscribe messaging protocol for constrained Internet of Things (IoT) devices in low-bandwidth, high-latency, or unreliable networks. Advantech iSensing MQTT is an Advantech-defined MQTT topic and payload for iSensing and iConnectivity devices, including WISE-4000 wireless I/O, ADAM-6000 Ethernet I/O, and B+B Wizard mesh I/O.



There are two differences between WISE-4000 wireless I/O and ADAM-6000 Ethernet I/O:

1. WISE supports TLS/SSL but ADAM does not.
2. WISE uses a web socket format package and ADAM uses TCP format package.



*RSMB, Really Small Message Broker

*802.15.4 technical standard which defines the operation of low-rate wireless personal area networks (LR-WPANs)

A.1 iSensing MQTT Format for publishing

A.1.1 Topic Format: Advantech/IMEI/data

Field	Description
Advantech	Vendor of WISE Series
MAC (IMEI)	MAC address or IMEI of WISE Series
data	Topic for query the data of WISE Series

A.1.2 Payload Format


Field	Abbreviation	Description
Sequence Number	s	Sequence number that updates each time a sensor reading is made 0~9, 0~9, ...
Time Stamp	t	ISO 8601 timestamp of the UTC time when the sensor reading was made
Quality	q	Quality of the sensor reading 192: The value is good. There are no special conditions.
Configuration Change	c	Configuration change affecting the reading (e.g., scaling, calibration) 0~9, 0~9, ...
Digital Input	di	Digital Input Mode true/false Counter 0~4294967295 Frequency Mode 0~30000 (default unit: 0.1Hz), 0~300000 (default unit: 0.01Hz)
Digital Output	do	Digital Output: true/false
Analog Input	ai	Engineering value of analog input: -10000.000~10000.000 (unit: mV) -20.000~20.000 (unit: mA)
Temperature Sensor	temp	Temperature engineering data, the value is floating type. Unit: According range code For example, 999.120 -> 999.12 °C -3.220 -> -3.22 °C
Temperature Range Code	temprc	4096: Temperature (°C) 4097: Temperature (°F) 4098: Temperature (K)
Humidity Sensor	rh	Humidity engineering data, the value is floating type. Unit: According range code
Humidity Range Code	rhrc	4128: Humidity (%)
RS-485	p1v06r0012x05	p1: Port number v01: Slave ID s: Coil (r: Register) 00b1: Modbus/RTU address x02: Mapping channel

A.1.3 Example

Model Name	JSON Data	Notes
WISE-4012E (2-DI, 2-DO, 2-AI)	<pre>{ "s":6, "t":"2017-11-03T15:06:16Z", "q":192, "c":2, "di1":true, "di2":false, "do1":true, "do2":false, "ai1":-0.763, "ai2":-0.763, }</pre>	<ul style="list-style-type: none"> ■ The value of di1 and di2 can be: false, true. ■ The value of do1 and do2 can be: false, true ■ The value of the sensor in engineering units if ai disable the value is 9999.9999 <p>"ai_st": AI status number meaning: 0, AI Channel disable 1, Streaming 2, High latch 3, High momentary 4, Low latch 5, Low momentary</p>
WISE-4012 (4-DO, 4-AI)	<pre>{ "s":6, "t":"2017-11-03T15:06:16Z", "q":192, "c":2, "do1":true, "do2":false, "ai1":-0.763, "ai2":-0.763, "ai3":-0.763, "ai4":-0.763 }</pre>	<ul style="list-style-type: none"> ■ The value of do1 and do2 can be: false, true ■ The value of the sensor in engineering units if ai disable the value is 9999.9999 <p>"ai_st": AI status number meaning: 0, AI Channel disable 1, Streaming 2, High latch 3, High momentary 4, Low latch 5, Low momentary</p>
WISE-4050 (4-DI, 4-DO)	<pre>{ "s":6, "t":"2017-11-03T15:06:16Z", "q":192, "c":2, "di1":true, "di2":false, "di3":true, "di4":false, "do1":true, "do2":false, "do3":true, "do4":false, }</pre>	<ul style="list-style-type: none"> ■ The value of di1 and di2 can be: false, true. ■ The value of do1 and do2 can be: false, true
WISE-4060 (4-DI, 4-DO)	<pre>{ "s":6, "t":"2017-11-03T15:06:16Z", "q":192, "c":2, "di1":true, "di2":false, "di3":true, "di4":false, "do1":true, "do2":false, "do3":true, "do4":false, }</pre>	<ul style="list-style-type: none"> ■ The value of di1 and di2 can be: false, true. ■ The value of do1 and do2 can be: false, true

WISE-4051 (8-DI, 1-RS-485)	<pre>{ "s":6, "t":"2017-11-03T15:06:16Z", "q":192, "c":2, "di1":true, "di2":false, "di3":true, "di4":false, "di5":true, "di6":false, "di7":true, "di8":false, "p1ffr0001x01":348, "p1v06r0012x05":32768 "p1v01s00b1x03":true, "p1v12s012dx0f":false }</pre>	<ul style="list-style-type: none"> ■ The value of di1 and di2 can be: false, true. ■ The value of coil can be: true, false. ■ The value of register can be 0x0 to 0xFFFF.
WISE-4220-S231 (1-Temperature, 1-Humidity)	<pre>{ "s":6, "t":"2017-11-03T15:06:16Z", "q":192, "c":2, "temp1":23.6, "temp1rc":4096, "rh1":43.6, "rh1rc":4128 }</pre>	<ul style="list-style-type: none"> ■ Temperature and range code in the configured engineering units ■ The humidity in % unit and range code.
WISE-4470-S250 (6-DI, 2-DO, 1-RS-485)	<pre>{"s":1, "t":"2014-07-11T15:26:37Z", "q":192,"c":1, "di1":false,"di2":true "do1":false,"do2":true "p1ffr0001x01":348, "p1v06r0012x05":32768 "p1v01s00b1x03":true, "p1v12s012dx0f":false}</pre>	<ul style="list-style-type: none"> ■ The value of di1 and di2 can be: false, true. ■ The value of do1 and do2 can be: false, true ■ The value of coil can be: true, false. ■ The value of register can be 0x0 to 0xFFFF.
WISE-4470-S214 (4-AI, 4-DI)	<pre>{"s":1, "t":"2014-07-11T15:26:37Z", "q":192,"c":1, "ai1":-1.234567, "ai_st1":1, "ai2":-123.4567, "ai_st1":2 "di1":false,"di2":true }</pre>	<ul style="list-style-type: none"> ■ The value of the sensor in engineering units if ai disable the value is 9999.9999 <p>"ai_st": AI status number meaning: 0, AI Channel disable 1, Streaming 2, High latch 3, High momentary 4, Low latch 5, Low momentary</p> <p>The value of di1 and di2 can be: false, true.</p>
WISE-4471-S250 (6-DI, 2-DO, 1-RS-485)	<pre>{"s":1, "t":"2014-07-11T15:26:37Z", "q":192,"c":1, "di1":false,"di2":true "do1":false,"do2":true "p1vffr0001x01":348, "p1v06r0012x05":32768 "p1v01s00b1x03":true, "p1v12s012dx0f":false}</pre>	<ul style="list-style-type: none"> ■ The value of di1 and di2 can be: false, true. ■ The value of do1 and do2 can be: false, true ■ The value of coil can be: true, false. ■ The value of register can be 0x0 to 0xFFFF.

WISE-4471-S214 (4-AI, 4-DI)	<pre>{ "s":1, "t":"2014-07-11T15:26:37Z", "q":192,"c":1, "ai1":-1.234567, "ai_st1":1, "ai2":-123.4567, "ai_st1":2 "di1":false,"di2":true }</pre>	<ul style="list-style-type: none"> ■ The value of the sensor in engineering units if ai disable the value is 9999.9999 <p>"ai_st": AI status number meaning:</p> <ul style="list-style-type: none"> 0, AI Channel disable 1, Streaming 2, High latch 3, High momentary 4, Low latch 5, Low momentary <p>The value of di1 and di2 can be: false, true.</p>
--------------------------------	--	--


Note!  The channel number on WISE module is "0" based, and the channel number of MQTT topic is "1" based. For example: "DO0" of WISE module use topic "do1"

A.2 iSensing MQTT Format for subscribing

A.2.1 Topic Format: Advantech/IMEI/ctl/dolIndex


These topics are used to control the digital outputs on the sensors that support them. These requests need to be published to the broker handling the Sensor network.

Field	Description
Advantech	Vendor of WISE Series
IMEI	MAC address of WISE Series
dolIndex	The index of the DO channel. Note that the index start with '1'

Note!  The channel number on WISE module is "0" based, and the channel number of MQTT topic is "1" based. For example: "DO0" of WISE module use topic "do1"

A.2.2 Payload Format

JSON data	Description
{"v":true}	Setup the DO Boolean value as true
{"v":false}	Setup the DO Boolean value as false

Note!  While sending control MQTT command, do not set the retain bit when publishing messages to this topic. Otherwise, an old retained message may change the state of the output.

A.2.3 Example

Model Name	Topic	JSON Data	Description
WISE-4012E (2-DI, 2-DO, 2-AI)	Advantech/MAC/ctl/do1	{"v":true}	The DO0 value will be set as true.
WISE-4050 (4-DI, 4-DO)	Advantech/MAC/ctl/do2	{"v":false}	The DO1 value will be set as false.
WISE-4470-S250UA (6-DI,2-DO, 1-RS-485)	Advantech/IMEI/ctl/do3	{"v":false}	The DO2 value will be set as false.
WISE-4471-S250UA (6-DI,2-DO, 1-RS-485)	Advantech/IMEI/ctl/do1	{"v":true}	The DO0 value will be set as true.

Note! *The channel number on the WISE module is "0" based, and the channel number of MQTT topic is "1" based. For example: "DO0" of WISE module use topic "do1"*



Appendix **B**

EU Declaration of
Conformity (DoC)

B.1 EU Declaration of Conformity (DoC)

Hereby we,

Name of manufacturer: ADVANTECH CO., LTD
Address: No.1, Alley 20, Lane, Ln. 365, Yangguang St., Neihu Dist.,
Zip code & city: Taipei City 114
Country: Taiwan (R.O.C.)
Telephone number: +886 2 2792-7818

declare that this DoC is issued under our sole responsibility and that this product:

Product description: IoT Wireless Sensor Node
Type designation(s): WISE-4471
Trademark: Advantech
Batch / Serial number: NA

Object of the declaration (further identification of the radio equipment allowing traceability; it may include a color image for the identification of the radio equipment): **NA**



is in conformity with the relevant Union harmonization legislation:

Radio Equipment directive: 2014 / 53 / EU

and other Union harmonization legislation where applicable:

with reference to the following standards applied:

EN 301 908-1 V11.1.1(2016-07)

EN 62311:2008

EN 55032:2015 +AC:2016, Class A

EN 55024:2010 +A1:2015

EN 55011:2009+A1:2010

EN 61000-6-4:2007+A1:2011

EN 61000-6-2:2017

EN 301 489-1 V2.1.1(2017-02)

EN301489-52 V1.1.0(2016-11)

The Notified Body Telefication B.V., with Notified Body number 0560 performed:

[choose applicable Modules: B+C or H]

Where applicable:

The issued EU-type examination certificate: [note certificate number]

Description of accessories and components, including software, which allow the radio equipment to operate as intended and covered by the DoC:

.....

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2018