

WISE-2200-M		
	Serial Port	1

Modbus RTU

Address 0X	Ch	Description	Attribute	Address 4X	Ch	Description	Attribute
01001 ~ 01128	0~127	COM1 Bit value	R/W	41001 ~ 41128	0~127	COM1 Word value	R/W
				41201 ~ 41327	0~127	COM1 Bit value error code	Read
				41401 ~ 41527	0~127	COM1 Word value error code	Read

(Addr): Upper word
(Addr+1): Lower word

Miscellaneous

Address 0X	Ch	Description	Attribute	Address 4X	Ch	Description	Attribute
5001		RTC Battery Low Event	Read	45001		RTC Battery Voltage	Read
5002		(Main) Battery Low Event	Read	45002		External Power (mV)	Read
				45003		Main Battery Voltage	Read
				45004		Battery Level (0 ~ 100 %)	Read
				45005		Battery Status (*6)	Read
				45006		Power source (*4)	Read
				45011	(Upper word)	Timestamp	Read
				45012	(Lower word)		
				45101		Data Logger Status	Read
				45301		RSSI (unit: -dBm)	Read
				45302		SNR (unit: dB)	Read
				45311~45314		*Device EUI (EUI-64)	Read
				45315~45316		Frame FCntUp	Read
				45317~45318		Frame FCntDown	Read
				45319		Packet Loss (0.01%)	Read

5001 ~ 5099 : System Information
5101 ~ 5199 : Data Logger

(Addr): Upper word ~
(Addr+3): Lower word
* ABP mode: 45311~45312: 0000
45313~45314: DevAddr of ABP
* OTAA mode: 45311~45314: EUI-64