

Python 3 install on ECU-150 – Ubuntu 20.04

Testet on ECU-150 with Ubuntu 20.04 image v1.9.0

Please enter the following commands in SSH:

```
sudo apt-get update
```

```
sudo apt-get install python3-pip
```

```
pip3 -V
```

```
python3 -m pip install pyserial
```